



CRATE CREATURE PUPPET

USE/CARE GUIDE

Includes:

- Creature Puppet
- Carry crate
- Fake arm
- Safari-type shirt, lab coat or black hoodie, depending on puppet type.
- Puppet Master Sound System™



1. The shirt has a third sleeve in the front for your right arm. The right sleeve has a fake arm that snaps to the harness at the shoulder. The arm can be removed to wash the shirt.



2. The shirt has velcro for easy on/off. Buttons are attached on front for effect.



3. The fake arm is attached to the crate with a snap as shown.




4. To puppeteer the creature, simply slip your hand into it through the access hole in the back of the crate.

Puppet Master Sound System™



Note: See manufacturer's details on the sound system for operation and charging. Adjust sound level as needed.



5. The Puppet Master Sound System™ is located in the crate with the dino puppet. There is a flap of burlap material to keep it hidden.

Note: To change audio clips on your system download software and audio clips at <http://www.vfxcreates.com/downloads/>



6. Audio control buttons for the sound effects are located on the bottom of the crate for easy access with your left hand.

NOTE: Practice in the mirror and get use to the sound effects to create a realistic illusion.

VFX - VFXcreates.com

618.530.7982